





**DayMen Lowepro**  
**Point&Shoot Pouch Fit Guide**  
 April 2011

			Nylon Pouches							Neoprene Pouches					Hard Cases		Leather					
			Box	Classified	Serrano	Razo	Ridge	Stockholm	Manish	Manish 100	Adventura UZ 100	Sansalto	Sciffle	Dublin	Hypshot	Melbourne	Vera	Santiago	Vela	Sorrento	Perolino	Summary - Total Number of Pouch fits
Samsung	HZ30W	WB500	30	30	30	30	30															7
Samsung	HZ35W	WB550	30	30	30	30	30															6
Samsung	HZ50W	WB5500	30	30	30	30	30			100	100											2
Samsung	NX100	NX100	60			50	20/30							30								6
Samsung	PL200	PL200	20/30			20/30	5/10			10/20				10	10/20	10	10	10/20	10/20	10	20	19
Samsung	SL102	ES55	10/20		10	15	5/10	10	10				20	20	10/20	10	10	10/20	10/20	10	10	25
Samsung	SL202	FL50	10/20		10	15/20	5/10	10	10				20	20	10/20	10	10	10/20	10/20	10	10	18
Samsung	SL30	ES15	10/20			15/20	5/10						20	20	10/20			20	20	10/20	20	17
Samsung	SL40	SL40	10/20			15/20	5/10						20	20	10/20			20	20	10/20	20	15
Samsung	SL420	SL420	10/20		10	15	5/10						20	20	10/20	20		10/20	10/20	10	20	18
Samsung	SL50	SL50	20/30	30		20/30	5/10	10/20					10	10/20	10	10	10/20	10/20	10	20	20	20
Samsung	SL600	SL600	20/30	30		20/30	5/10	10/20					10	10/20	10	10	10/20	10/20	10	20	20	20
Samsung	SL605	SL605	20/30	30		20/30	5/10	10/20					10	10/20	10	10	10/20	10/20	10	20	20	20
Samsung	SL620	PL65	10/20		10	15	5/10	10					20	20	10/20	20		10/20	10/20	10	20	18
Samsung	SL720	PL70	10/20		10	15/20	5/10	10					20	20	10/20	20		10/20	10/20	10	20	17
Samsung	SL780	SL780	10/20		10	15/20	5/10	10	10	10/20				10	20			10/20	10/20	10	20	20
Samsung	TL100	ST50	20/30		10	20/30	5/10	10					20	20	10/20	10/20	10	10	20	10/20	10	19
Samsung	TL105	TL105	20/30		10	20/30	5/10	10					20	20	10/20	10/20	10	10	20	10/20	10	20
Samsung	TL110	TL110	20/30		10	20/30	5/10	10					20	20	10/20	10/20	10	10	20	10/20	10	19
Samsung	TL205	PL100	20/30	30	10	20/30	5/10	10/20	10/20				10	10/20	10	10	10/20	10/20	10	20	20	23
Samsung	TL210	PL150	20/30	30	10	20/30	5/10	10/20	10/20				10	10/20	10	10	10/20	10/20	10	20	20	23
Samsung	TL220	ST500	20		10	20/30	5/10	10	10/20				20	20	10/20	10	10	10/20	10/20	10	20	18
Samsung	TL225	ST550	20		10	20/30	5/10	10	10/20				20	20	10/20	10	10	10/20	10/20	10	20	16
Samsung	TL240	ST5000	20/30			30		20					20	20	10	10	10/20	10/20	10	20	20	8
Samsung	TL350	WB2000	20/30	30		20/30	10/20	10/20					20	20	10	10/20	10	10	10/20	10/20	10	20
Samsung	TL420	EX1	60			60								30								3
Sony	Cybershot DSC-H20	DSC H20	20/30	30	30									30								3
Sony	Cybershot DSC-H55	DSC H55	20/30	30	30	50	20	20					20	20	20	20/30						13
Sony	Cybershot DSC-H11	DSC H11	10/20	10	10			10	10				20	20	10	10/20	10	10	20	10/20	20	14
Sony	Cybershot DSC-HX5V	DSC HX5V	30	30	30	50	20	20					20	20	20	30						10
Sony	Cybershot DSC-HX7V	DSC HX7V	20/30	30	30	20/30	20/30	20					20	20	20	10/20/30						10
Sony	Cybershot DSC-HX9V	DSC HX9V	20/30	30	30	30/50	20/30	20					20	20	30							10
Sony	Cybershot DSC-HX100V	DSC HX100V							100	100												2
Sony	Cybershot DSC-S1900	DSC S1900	20/30			20/30	20/30	20					20	20	20	20/30						14
Sony	Cybershot DSC-S2100	DSC S2100	20/30			20/30	20/30	20					20	20	20	20/30						15
Sony	Cybershot DSC-T110	DSC T110	10/20		10	15/20	5/10	10	10/20					10	10	10	10	10/20	10/20	10	20	20
Sony	Cybershot DSC-T190	DSC T190	20		10			10	10				20	20	10	10/20	10	10	10	10	20	21
Sony	Cybershot DSC-T198	DSC T198	10/20		10	15/20	5/10	10	10/20					10	10	10	10	10/20	10/20	10	20	21
Sony	Cybershot DSC-TX1	DSC TX1	10/20		10			10	10				20	20	10	10/20	10	10	20	10/20	20	14
Sony	Cybershot DSC-TX10	DSC TX10	10/20		10	15/20	5/10	10	10				20	20	10	10	10	10/20	10	20	10	16
Sony	Cybershot DSC-TX5	DSC TX5	10/20		10	15	5/10	10	10				20	20	10	10	10	10/20	10	20	10	16
Sony	Cybershot DSC-TX7/TX9	DSC TX7/TX9						20												10	20	2
Sony	Cybershot DSC-W180	DSC W180	10/20			5	10	10					20	20	10	10/20			10/20	10/20	10	15
Sony	Cybershot DSC-W198B	DSC W198B	10/20			5	10	10					20	20	10	10/20			10/20	10/20	10	15
Sony	Cybershot DSC-W220	DSC W220	20/30		10		5/10	10					20	20	10/20	10/20	10	10	20	10/20	10	17
Sony	Cybershot DSC-W230	DSC W230	20/30		10		5/10	10					20	20	10/20	10/20	10	10	20	10/20	10	17
Sony	Cybershot DSC-W290	DSC W290	20/30		10		5/10	10	10/20				20	20	10/20	10/20	10	10	20	10/20	10	22
Sony	Cybershot DSC-W310	DSC W310	20		10	15	5/10	10/20	10				20	20	10	10/20	10	10	20	10/20	10	18
Sony	Cybershot DSC-W320	DSC W320	10/20		10	20/30	5	10	10/20				20	20	10	10	10	10/20	10	20	10	16
Sony	Cybershot DSC-W330	DSC W330	20		10	15	5/10	10/20	10				20	20	10	10	10	10/20	10/20	10	10	15
Sony	Cybershot DSC-W350	DSC W350	10/20		10			10	10				20	20	10	10	10	10/20	10/20	10	10	15
Sony	Cybershot DSC-W360	DSC W360	10/20	30	10	15/20	5/10	10/20	10/20				20	20	10	10/20	10	10	10/20	10/20	10	20
Sony	Cybershot DSC-W370	DSC W370	20/30		10		5/10	10	10/20				20	20	20	20	20	20	10/20	10/20	10	24
Sony	Cybershot DSC-W380	DSC W380	10/20	30	10	20/30	5	10	10				20	20	10	10	10	10/20	10/20	10	10	17
Sony	Cybershot DSC-W390	DSC W390	10/20	30	10	15/20	5/10	10/20	10/20				20	20	10	10/20	10	10	10/20	10/20	10	20
Sony	Cybershot DSC-W510	DSC W510	20	30	10	20/30	5/10	10/20	10/20				20	20	10	10/20	10	10	10/20	10/20	10	20
Sony	Cybershot DSC-W530	DSC W530	10/20		10		5	10	10/20				20	20	10	10/20	10	10	10/20	10/20	10	24
Sony	Cybershot DSC-W560	DSC W560	10/20		10	15/20	5/10	10	10/20				20	20	10	10	10	10/20	10/20	10	10	21
Sony	Cybershot DSC-W570	DSC W570	10/20		10	20/30	5	10	10				20	20	10	10	10	10/20	10/20	10	10	20
Sony	Cybershot DSC-WX1	DSC WX1	10/20		10			10	10				20	20	10	10	10	10/20	10/20	10	10	13
Sony	Cybershot DSC-WX10	DSC WX10	10/20		10	20/30	5/10	10/20	10/20				20	20	10	10	10	10/20	10/20	10	10	19
Sony	Cybershot DSC-WX5	DSC WX5	10/20	30		20/30	5	10	10/20				20	20	10	10	10	10/20	10/20	10	10	16
Sony	MHS CM6V	MHS CM6V	60	30	30		35							20/30	30							8
Sony	MHS PMS	MHS PMS	20	10	10	30/50		20								10	10	30	20			8
Vivitar	VivCam 25	VivCam 25	30	30			5/20						20	20	20					20	20	8
Vivitar	VivCam 5022	VivCam 5022	20	10	10		5/10	10					20	20	10	10/20	10	10	20	10/20	10	15
Vivitar	VivCam 5024	VivCam 5024	10	10	10		5/10	10					20	20	10	10	10	10	20	10/20	10	12
Vivitar	VivCam 7022	VivCam 7022	10	10	10		10/20	10					20	20	10	10	10	10	10	10/20	10	8
Vivitar	VivCam 8118	VivCam 8118	10/20	30	20		5	10					20	20	10	10	10	10	10	10/20	10	13
Vivitar	VivCam 8025	VivCam 8025	10/20		10	15		10	10				20	20	10	10	10	10/20	10/20	10	10	15
Vivitar	VivCam 8225	VivCam 8225	10/20		10	15	5/10	10	10				20	20	10	10	10	10/20	10/20	10	10	17
Vivitar	VivCam V15	VivCam V15	30			30		20						20								5
Vivitar	VivCam V7024	VivCam V7024	10/20	30	20			20					20	20	20				10/20	10	10	10/20
Vivitar	VivCam VX018	VivCam VX018	10/20	30	30	20	5	20					20	20	10	10/20	10	10	10	10		